


# Assembly

## 1 Assembling the beams

- Unfold the beam 2 (F) and insert the beam 1 (E) to the corner of the screen. Then secure them by using the top buckle.



**NOTE:** To avoid destroying the finish, please handle it with care.




## 2 Attaching the beam connectors

- Insert the beam connectors (C) into the beam 2 (F).




**NOTE:** To avoid destroying the finish, please handle it with care.




## 3 Attaching the top beams

- Insert the top beams (B) into the beam connectors (C).



## 4 Attaching the top beams to the connector

- Insert the top end of the top beams (B) into the connect tube of the top connector (A).




## Assembly (continued)

### 5 Attaching the middle beams

- Insert the middle beams (D) into the middle connect tubes of each screen 1 (E).



**NOTE:** To avoid destroying the finish, please handle it with care.




### 6 Securing the middle beams

- Insert the middle beams (D) into the connect tubes of the top connector (A) and attach the hook (G). Place the big canopy (I) on top of the assembly, but do not unfold it.




**NOTE:** To avoid destroying the finish, please handle it with care.



### 7 Attaching the canopies

- Unfold the big canopy and tie. Then secure the four corners of the small canopy (H) to the top of the assembly.



### 8 Completing the assembly

- Secure the gazebo to the ground using the stakes (AA).

